

Installation Guidelines for Power and Telecommunication Pads

The following installation procedure is the same for all sizes of foundation pads.

1. Determine cable/conduit entry position.
2. Excavate around cable entry position to accommodate size of pad to be installed and sub-grade fill as specified by utility standards. Recess area as required so pad face will be three inches above grade when installation is complete. Provide any soil treatments as specified by utility standards.
3. Level dirt around cable opening.
4. Level and tamp down dirt in the area to be occupied by the foundation pad.
5. Remove plastic protective covers from inserts to be used with a pair of pliers. Discard.
6. Place pad in prepared, level area with opening in pad (throat) directly over cable entry position.
8. Attach cabinet to the foundation pad with bolts, brackets, and/or lugs provided by cabinet manufacturer.
9. Backfill and tamp earth around pad so it is level with surrounding landscape.