

## Standard Small Enclosure Installations

### ***Installation Guidelines for Enclosure Sized 2448 and Smaller:***

#### **1. Prepare the Excavation**

- 1.01 Excavate approximately 10 inches greater around the actual outside dimension of the Enclosure to be installed and 6 inches deeper than to depth will be required for installation.
- 1.02 Add 6 inches of gravel or crushed rock for drainage.

#### **2. Place Enclosure in Hole**

- 2.01 Top of Enclosure should be at grade level.

#### **3. Fill and Compact Soil**

- 3.01 Fill to grade level with cover in Enclosure.

#### **4. Grade Adjustment**

- 4.01 If grade level is raised later, a straight sided Enclosure can be pulled up and bricked at the bottom on one or four sides to conform to the landscape.